

Hardwood Timber & Ekki Bog Mats



Temporary Access Mats



Medium Duty



Heavy Duty

Description

All of our Hardwood Timber Bog Mats are manufactured from European hardwood, or Ekki Bog Mats also from European or tropical hardwood, which are both hardwearing when used as a temporary roadway application in all fields of the construction industry.

As they're environmentally friendly, all mats are reusable and cause minimum ground disturbance and are sourced from contracted sawmills in which respect National Forest Management Plans.

Guide price

From £193.20 (excl. VAT)

*We advise checking any agreed or pre-authorised disclaimers on our website before installing or using any of our products, along with live updated and discounted prices available.

- ✓ Various sizes and thicknesses available
- ✓ Supports heavy plant and machinery
- ✓ Can be used with steel tracked vehicles
- ✓ No need to connect
- ✓ Enable access with extremely soft and boggy ground



We won't be beaten on price - find it cheaper and we'll beat it!

Specifications

 Size	Standard: 3m / 5m / 6m [L] x 1m [W] x 70-300mm [H] Ekki: 3 / 4m / 5m / 6m / 7m [L] x 1m [W] x 70-200mm [H]
 Weight	312-2298Kg (depending on size and mat type)
 Handholes/connection holes	2 lifting points
 Load	30-120 tonnes
 Material	100% Hardwood Timber / Ekki - view both of our technical sheets for more information
 Regulatory	National Forest Management Plans via contracted sawmills

Hardwood Timber Bog Mats or Ekki Bog Mats are used to provide access for both rubber and tracked vehicles in areas with difficult ground conditions, often in wet conditions or where the tracks of a vehicle might damage the ground. Even where access is required over underground services they are suitable for all types of application to take weights well in excess of 50+ tonnes.



These mats are produced to a very high standard using 5 x 200mm beams, and depending on the size of the mat, 18mm to 24mm bolts, all countersunk with strong washers and nuts to give a smooth finish, and are complete with 2 lifting bolts/eyes as standard.

Contact us to find out about products available for hire and finance.

Step 1



Step 2



Step 3



Step 4



[Download MultiMatts Brochure](#)

How to install the Hardwood Timber Bog Mats



Preparation

Create a stable foundation before installing and we recommend, where possible, that the ground is levelled before use.



Installation

The Timber Bog Mats should be lifted by crane or heavy duty forklift with the pre-punched lifting holes at each side. Manual handling should be avoided, only assisting to lay them into position.



Connection

There is no need for connection. These Hardwood Timber Bog Mats will settle and compact into place with use.