

K-Mat OL Heavy Duty Roadway Panels



Temporary Access Mats



Heavy Duty

Description

Temporary trackway panel that provides robust access and ground protection for heavy plant and machinery, across demanding environments in a wide range of industries and applications.

Designed with safety and performance in mind, each panel features an ultimate grip surface, with high-traction profile for vehicles on one side, and non-slip texture on the other to ensure secure footing for pedestrians and site workers.

Guide price
£POA

*We advise checking any agreed or pre-authorised disclaimers on our website before installing or using any of our products, along with live updated and discounted prices available.

- ✓ Ability to support extremely heavy loads in varied weather conditions
- ✓ Avoids health and safety issues and is non-conductive
- ✓ Various connection points
- ✓ Reduces the chance of vehicles from becoming bogged

We advise not to use Steel Tracked vehicles with any composite mats unless pre-authorised and agreed beforehand, traversing and aggressive movement on the mats may cause damage to them and the connectors and this will be the sole responsibility of the customer and user of the mats.



**We won't be beaten on price -
find it cheaper and we'll beat it!**

Specifications

 Size	Full size: 3000mm [L] x 2000mm [W] x 40mm [H] Half size: 1720mm [L] x 920mm [W] x 12mm [H]
 Weight	295Kg / 32Kg (est.)
 Handholes/connection holes	0 handholes and 5 connection holes / 6 connection holes
 Load	160 T (Depending on ground conditions)
 Surface	Top: High profile traction surface Bottom: Low profile non-slip surface
 Material	100% Recycled Ultra High Molecular Weight Polyethylene (UHMWPE) and 100% recyclable
 Colour	Black or hi-vis yellow

Specialist lifting equipment such as a Hiab or heavy duty forklift is required, as well as mechanical fixing to install the K-Mat OL Heavy Duty Roadway Panels.

We offer a variety of connection methods to suit varying ground conditions and applications. The simplest way to install the K-Mat OL panels is to place them onto the ground where required and secure into place using the suitable metal strap connectors.



Contact us to find out about products available for hire and finance.

Step 1



Step 2



Step 3



Step 4



Download MultiMatts Brochure

How to install the K-Mat Heavy Duty Roadway Panels



Preparation

It is recommended that the ground is graded and levelled before use. Ideally a non-woven filtration textile should be laid.



Installation

The mats should be lifted by specialist equipment such as a Hiab or Heavy Duty Forklift. Safely move the K-Mat OL Heavy Duty Roadway Panels whilst being guided by another person. Please ensure correct manual handling procedures are followed.



Connection

Overlay the mat edges together and secure in place with Cam Locks (full size mat), or tighten with Bolts (half size mat).